



Get cooking quicker

This Full electric cooker heats up faster than standard ceramic hobs. So whatever you're heating – butter for scrambled eggs, oil for sausages, and water for vegetables – is ready sooner.

Product Benefits & Features
A glass door that's simple to keep clean

The glass in this oven's door is simple to clean. You can completely remove the door and the glass panels, and quickly clean it all.


New removable oven door makes cleaning quick and easy

Thanks to a new hinge system, this oven door on the cooker can be removed for easier cleaning. This means you can get at every part of it, even the hard-to-reach places.

Locked for child safety

This easily removed mechanical door lock protects your children against burns.

- Cooker with electric oven and hob
- Hob type: Ceramic Glass
- Hob lid type:
- Left front cooking zone: Hilight, 1800W/180mm
- Left rear zone: Hilight, 1200W/140mm
- Right front cooking zone: Hilight, 1200W/140mm
- Right rear zone: Hilight, 1800W/180mm
- Oven type: Electrical
- Top oven functions: Bottom heat, Conventional/Traditional cooking, Conventional/Traditional light cooking, Fast grilling, Light, Low temp. cooking/Slow cooking, Quick heat
- Bottom oven functions:
- Oven functions: Bottom heat, Conventional/Traditional cooking, Conventional/Traditional light cooking, Fast grilling, Light, Low temp. cooking/Slow cooking, Quick heat
- Controls for 4 energy regulated cooking zones
- Oven Cleaning: Black Enamel
- Easy to clean oven door
- Rear exhaust for oven fumes
- Drawer for storage of cooking utensils
- Electric cable length: 1.6 m

Product Specification

Product Installation	Free_Standing		Low energy cooking=bottom+top at 500W.
Product Typology	Single_Cav_Electric	Other comments design	full glass door
Product Classification	Core		Avanti knobs,handle and door.
Installation	Slot In		The logo on the door is Electrolux
Size	50x60	Height at hob	898
Hob type	Ceramic Glass	Height adjustment	858-923
Oven Energy	Electrical	Width mm	500
Cooking	Traditional+Grill	Depth mm	600
Cleaning top oven	Black Enamel	Gas original	No
Electrical supply - Cooker functioning	Mains	Gas replacement 2	No
Nº of cavities	1	Gas replacement 3	No
Design family	Avanti		
Main colour	White		
Control Panel material	Steel		
Type of handle	Plastic, Towel Rail		
Door Handle Colour	White		
Type of doors	2 Glasses		
Pan storage	Drawer, Steel		
Control lamps	Hob, Thermostat Indicator		
Thermostat	Top		
Type of timer min.	No		
Cooking function top oven	Bottom, Grill + bottom, Grill + top, Top + bottom, Top + bottom (LTC), Top + bottom + grill		