Russell Hobbs SatisFry Air Medium – Yes you can

Product name, model number & proposition line.

Product summary

Enjoy carefree cooking that'll save you time and energy in the kitchen with the Russell Hobbs Satisfry Medium. Easy touch screen controls and 10 pre-set programmes allow you to make a wide range of dishes with no fuss, or mess. While air fry technology circulates temperatures up to 220 °C – with little or no oil required. So, if you think cooking from scratch can be time-consuming and messy, think again! With a dishwasher safe** fry basket and crisping plate, the Russell Hobbs Satisfry Medium is a fast, convenient and tasty way for all the family to enjoy the meals and snacks they love.

Paper summary

Save time and energy with the Russell Hobbs Satisfry Medium. With 10 pre-set cooking programmes, air fry technology and dishwasher safe** parts, mealtimes are delicious and easy – with minimum clean up required afterwards!

Key features

4 Litre capacity

The SatisFry Air Medium has a generous 4L capacity, which is large enough to hold a maximum 800g capacity of chips. 500g is recommended for best browning results.

Energy saving

Saves up to 46% energy compared to a conventional oven.

Shake reminder

The shake reminder is an alarm that sounds halfway through the cooking cycle, for foods like chips and nuggets that need a shake for that delicious, crispy crunch.

Air fry technology

Air fry technology circulates super-heated air at high speed, with temperatures up to 220 °C.

10 pre-set food programmes

Whatever's on your menu, 10 pre-set functions allow you to select specific programmes for different food types: French fries, eggs, chicken, vegetables, air fry, bake, grill, dehydrate, cook from frozen and reheat. This means you'll enjoy your favourites just how you like them!

Intuitive digital touchscreen display

The touchscreen display helps you to stay in control of your cooking, from setting the temperature to programming the cooking method. It's easy to wipe clean too.

Dishwasher safe parts

The removable non-stick coated fry basket and crisping plate are dishwasher safe** and can be removed after every use, for ease of cleaning in the sink or dishwasher.

Timer with auto shut-off

Set the timer for up to 60 minutes at a time on most programs and manual settings, and up to 24 hours on the dehydrate programme. If you leave the appliance switched on when you've finished using it, it automatically shuts off after 20 seconds.

Variable temperature control

Set to the correct temperature for the food you're cooking. For example, starchy foods may need to cook at higher temperatures than delicate foods. Being able to manage the temperature puts you in control.

Product Spec List

- 4 Litre capacity
- Up to 46% energy saving*
- Shake reminder
- Air fry technology
- 10 pre-set food programmes
- Intuitive digital touchscreen display
- Dishwasher safe** parts
- · Timer with auto shut off
- Variable temperature control

Feature and benefits table

Feature	Benefit
4 Litre capacity	500g is recommended for best browning
	results. Can hold a maximum 800g
	capacity of chips.
Up to 46% energy saving	Compared to a conventional oven.
Shake reminder	When air frying chips, nuggets or other
	foods that need moving around to ensure
	a crispy crunch, you'll be reminded to
	shake the basket part-way through the
	cooking process.
Air fry technology	Circulates super-heated air at high speed,
	with temperatures up to 220 °C.

10 pre-set functions	10 pre-set functions so that you can select specific programmes for different food types: French fries, eggs, chicken, vegetable, air fry, bake, grill, dehydrate, frozen, reheat.
Intuitive touchscreen digital display	Helps you to stay in control of your cooking, from setting the temperature to programming the cooking method.
Dishwasher safe parts	Dishwasher safe** non-stick coated fry basket and crisping plate, for easy cleaning and dishwashing.
Timer with auto switch-off	Set the timer for up to 60 minutes at a time on most programs/manual settings, and up to 24 hours on dehydrate. If you leave the appliance switched on when you've finished using it, it automatically shuts off after 20 seconds.
Variable temperature control	Set the air fryer to cook at the optimum temperature for different foods. Being able to vary the cooking temperature puts you in control.

^{*}Vs a conventional oven

^{**}Tested on 100 dishwasher cycles