



- 1** A diagram showing the side of the lamp with a minus sign (-) indicating the battery location. To the right, a USB cable is shown with a USB A connector and a USB C connector. A clock icon with "4h" indicates the charging time.
- 2** A diagram showing the side knob being turned clockwise. A curved arrow indicates the direction of rotation, and a "click" sound icon is shown next to it.
- 3** A diagram showing the side knob being turned counter-clockwise. A curved arrow indicates the direction of rotation. To the right, a dimmer knob icon is shown with the text "DIMMABLE (20-40lm)".
- 4** A diagram showing a battery icon with three bars. A circular callout next to it says "UP TO 8h". An arrow points from the battery icon to the text "20LM".